

# DeltaSol & NeptuSol

| °C  | Ohm  | °C  | Ohm  |
|-----|------|-----|------|
| -10 | 961  | 55  | 1213 |
| -5  | 980  | 60  | 1232 |
| -0  | 1000 | 65  | 1252 |
| 5   | 1019 | 70  | 1271 |
| 10  | 1039 | 75  | 1290 |
| 15  | 1058 | 80  | 1309 |
| 20  | 1078 | 85  | 1328 |
| 25  | 1097 | 90  | 1347 |
| 30  | 1117 | 95  | 1366 |
| 35  | 1136 | 100 | 1385 |
| 40  | 1155 | 105 | 1404 |
| 45  | 1175 | 110 | 1423 |
| 50  | 1194 | 115 | 1442 |

Widerstandswerte der  
Pt1000-Sensoren

## Solarregler E1 / E1/D

| °C  | Ohm  | °C  | Ohm  |
|-----|------|-----|------|
| -10 | 1499 | 55  | 2502 |
| -5  | 1565 | 60  | 2592 |
| -0  | 1633 | 65  | 2684 |
| 5   | 1702 | 70  | 2778 |
| 10  | 1774 | 75  | 2874 |
| 15  | 1847 | 80  | 2971 |
| 20  | 1922 | 85  | 3071 |
| 25  | 2000 | 90  | 3172 |
| 30  | 2079 | 95  | 3275 |
| 35  | 2159 | 100 | 3380 |
| 40  | 2242 | 105 | 3484 |
| 45  | 2327 | 110 | 3590 |
| 50  | 2413 | 115 | 3695 |

Widerstandswerte der  
Halbleiterfühler

